

ELASTIKOTE™ RESTORATION PROTOCOL: EIFS

Series 100, 1000, 3000, 5000

2 Coat system

Existing EIFS Candidate

**Labor Sav 'R
Mastic
as needed**



**Prepare Any Defects with
ElastiKote Labor Sav 'R Mastic.**

ElastiKote Light Gray (1.50 gal per sq)

ElastiKote White (1.50 gal per sq)

Application

Complete Preparation Steps
(below)

Apply 1 st coat of ElastiKote
(Light Gray) at 1.50 gal per sq

Apply final coat of ElastiKote
(White) at 1.50 gal per sq

**TOTAL COMPLETED MILS_ 21 Dry
Mills**

**Each additional coat added @
1.50galpersqequals 10 dry
mils**

Preparation

Clean areas as needed with ElastiKote Substrate Cleaner and allow to soak for 30 minutes.

Rinse thoroughly with water and allow to dry

Repair ANY Suspicious Cracks, Improperly Protected Penetrations or Surface Defects with ElastiKote Labor Sav 'R Mastic