

NOTE: "BROOM" INTO PLACE DO NOT ROLL MEMBRANE
SO THAT BEADS ARE FLATTENED 'PAPER THIN'.

