


# ELASTIKOTE™ RESTORATION PROTOCOL: PLYWOOD

Series 100, 1000, 3000, 5000


2 Coat System

## Existing Plywood Candidate

**Labor Sav 'R & Sprayable Mastic**  
All Defects and Butt Joints  
With Separation Gap < 3/16" Wide



**SEBS Mastic with Scrim & Sprayable Mastic**  
As Needed  
With Separation Gap > 3/16"



### Application

Complete Preparation Steps (below)


Apply 1st coat of ElastiKote (Light Gray) at 1.5 gal per sq

Apply final wear coat of ElastiKote (White) at 1.5 gal per sq

**TOTAL COMPLETED MILS: 21 Dry Mils**

Each additional coat added @ 1.50 gal per sq equals 10 dry mils

**Labor Sav 'R**  
Seal All Knotholes



**Labor Sav 'R**  
(All Fastner Heads)



**ElastiKote Light Gray (1.50 gal per sq)**

**ElastiKote White (1.50 gal per sq)**

## Preparation

Mechanically remove all loose debris, dirt, biomass and any other foreign particulate by vacuum or broom. DO NOT POWER WASH

Surface must be dry, clean and free from dirt, loose rust and foreign substances.

All Fastener Heads, Defects, open, or severe "knot holes" are to be inspected and sealed with Labor Sav 'R and Sprayable Mastic.

Defects and Butt joints with a separation gap less than 3/16 inch are to be sealed with Labor Sav 'R Mastic and Sprayable Mastic. Defects and Butt joints with a separation gap greater than 3/16 inch are to be sealed with SEBS Mastic and scrim and Sprayable Mastic.