


ELASTIKOTE™ RESTORATION PROTOCOL: SINGLE PLY

Series 100, 1000, 3000, 5000

2 Coat System

Existing Single Ply Candidate



Preparation

Mechanically remove all loose gravel, dirt, etc. by vacuum, mechanical broom, power washing (1,000 – 1,500 psi) etc.

DONOT incorporate high-pressure water into existing roof assembly

Clean areas as needed with ElastiKote Substrate Cleaner

Thoroughly rinse and remove all cleaner residues

Surface must be dry, clean, and free from dirt, loose rust and foreign substances

Application

Complete Preparation Steps (above)

Apply 6" Band of ElastiKote (1.5 gal per sq) with reinforcement scrim embedded in it over all seams

Repair any surface tears, penetrations, expansion joints, curbs, etc. with Labor Sav'R Mastic (for defect gaps less than 3/16" at a minimum 3/16" thickness and a minimum 4" wide or SEBS Mastic and reinforcement scrim (for defect gaps greater than 3/16"))

Apply 1st coat of ElastiKote (Light Gray) at 1.5 gal per sq

Apply final wear coat of ElastiKote (White) at 1.5 gal per sq

TOTAL COMPLETED MILS_21 Dry Mils

Each additional coat added @ 1.50 gal per sq equals 10 dry mils